


# INSTRUCTIONS FOR USE

TANDYPRO® EDGING  
& CREASING MACHINE

3980-06

tandyPro<sup>®</sup>  
MACHINES



## INSTRUCTIONS FOR USE:

1. Attach the heating wand to the machine.
2. Screw on the desired tip.
3. Turn the machine on using on/off switch on back of machine.
4. Use the knob to select your desired temperature.
5. Allow the tip to heat up completely.
6. Slowly work the tip across the leather, pushing into the leather firmly .
7. When done, turn the machine off and set the wand into the groove on top of the box making sure the tip doesn't touch any surfaces until completely cool.

## CLEANING THE TIPS:

Brass Tips: Use high grit sandpaper (500 grit+) to remove any residue then buff the tip to remove any dust.  
Steel Tips: Wipe the tip with an alcohol wipe to remove residue. **DO NOT SAND STEEL TIPS.**

# TANDYPRO® EDGING & CREASING MACHINE



## INCLUDES

Machine  
10 Tips  
Wood Stand

## SPECIFICATIONS

Height: 6.5" (16.5 cm)  
Width: 10" (25.4 cm)  
Depth: 6" (15.2 cm)  
Weight: 3.57 lbs. (1.62 kg)

## CARE AND MAINTENANCE

Keep dry at all times and unplug when not in use.  
Do not modify machine in any way, doing so may result in malfunction or injury.  
Only use included tips with machine, other metals may cause malfunction or injury.



## WARNING

**BURN/SHOCK RISK:** Do not touch metal parts when in use.

**SHARP EDGES:** Use extreme caution.

**CHOKING HAZARD:** Small parts.

Product not intended for use by children; adult supervision is required. Always unplug machine when not in use. Do not touch sharp edges or metal parts to avoid injury. Read and understand the enclosed Instructions for Use before using this machine. Failure to follow operating instructions could result in serious injury.

## WARRANTY INFORMATION

Manufacturer warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of 6-months from the purchase date.

To request repair or damage support, please e-mail [tlfhelp@tandyleather.com](mailto:tlfhelp@tandyleather.com) and include the following information:

- 1) CUSTOMER ID/ORDER ID/DATE OF PURCHASE
- 2) MACHINE SERIAL #
- 3) PICTURES/VIDEO OF THE DEFECT
- 4) ADDITIONAL NOTES DESCRIBING THE ISSUE

Customer Service: 877-LEATHER  
[www.tandyleather.com](http://www.tandyleather.com)